genpa.com.tr

3IN1
KATLANA BİLİR 10.000 mAh GÜÇ STANTI
KULLANIM KLAVUZU

MENŞEİ VE İTHALAT BELGESİ
CEP TELEFONU AKSESUARI
Üretim Yeri: Çin
İthalatçi Firma: ER-TEL Erdem Telekomünikasyon Elektronik ve Bilgi İşlem San. Tic. A.Ş.
Nispetiye Cad. No:101 Etiler 34337 Beşiktaş/İstanbul
Tel:0212 359 00 00 Fax: 0212 287 39 39

GNP

KULLANIM KLAVUZU

3IN1 KATLANA BİLİR
10.000 mAh GÜÇ STANTI

Genel Bakış

	Yeşil LED: Tüm kablosuz çıkışlar hazır, cihazları kablosuz şarj için yerleştirebilirsiniz.
	Beyaz LED: Bir veya tüm kablosuz çıkışlar çalışıyor, başka bir cihazı kablosuz olarak şarj etmek istiyorsanız güç düğmesine basın.
	LED Kapalı, Kablosuz Kapalı.

	1%-25%
	26%-50%
	SUI-75"
	76%-100"

1) Kablosuz Şarj Göstergesi
2) Pil Seviyesi Göstergesi
3) Şarj ve Deşarj için USB-C Portu
4) Güç Düğmesi
5) Katlanabilir Stand
6) Telefon için Kablosuz Şarj Cihazı
7) Saat için Kablosuz Şarj Cihazı
8) AirPods için Kablosuz Şarj Cihazı

Kablosuz Şarj

NOT: Manyetik işlev yalnızca MagSafe şarjlı telefonlarla (iPhone 12 / 13 / 14 serisi veya daha yenisi) veya MagSafe kılıfı olan telefonlarla çalışır.
Kablosuz şarjı etkinleştirmek için güç düğmesi ne basın.
Cihazları şarj almak için belirlenen alana yerleştirin.

Power Bank Şarj Etmek

1)Bu güç bankası, bir USB-C kablosu ve şarj cihazı ile şarj edilebilir.
2)En iyi şarj deneyimi için 20W veya üzeri bir şarj cihazı gereklidir.

Cihazlarınızı kablo ile şarj edin

USB-C portu maksimum 20W çıkış sağlar, bu portu kullanarak diğer cihazları bir kablo ile şarj edebilirsiniz.

Power Bank ve Cihazınızı Birlikte Şarj Edin

Power bank çoklu şarjını destekler, bu sayede 3 cihazı ve powerbnkınızı aynı anda şarj edebilirsiniz.

1)Güç bankasını bir kablo ve şarj cihazı ile şarj edin.
2)Kablosuz şarj cihazınızı kablosuz şarj alanına yerleştirin.
3)Cihazınızın şarj olduğundan emin olun.

Önemli notlar

Bu kablosuz şarj cihazı, Otterbox Defender kılıfları gibi MagSafe olmayan telefon kılıflarıyla uyumlu değildir.
1.) 5V/2A (10W) çıkıştan daha düşük bir adaptör kullanmayın.
2) Kablosuz şarj cihazları, kablolu şarj cihazlarına göre daha kullanışlıdır, ancak mevcut kablosuz teknoloji ile sınırlı olduklarından, şarj hızları kablolu şarj cihazlarına göre daha yavaştır.
3) Yüksek sıcaklıklar şarj hızını azaltır ve gücü kısıtlar, bu tüm kablosuz şarj cihazlarında meydana gelen bir durumdur. Cihazınızı 25°C / 77°F'nin altındaki sıcaklıklarda şarj etmeniz önerilir.
4) Hem koruyucu telefon kılıfı hem de cihazınızın kablosuz şarj cihazı üzerindeki konumu şarj hızını etkiler. Cihaz, kablosuz şarj cihazının merkezinden ne kadar uzak yerleştirilirse, şarj hızı o kadar yavaş olur.

Güvenlik Önlemleri

Bu ürünü kullanırken, aşağıdaki temel önlemler de dahil olmak üzere her zaman dikkat edilmesi gerekenler:
1)Ürünü serin ve kuru bir yerde saklayın.

2)Ürünü sıcak veya nemli bir ortamda saklamayın.
3)Üretici tarafından önerilmeyen veya satılmayan bir güç kaynağı veya şarj cihazının kullanılması yangın veya yaralanma riski oluşturabilir.
4)Çalışma sıcaklığı 0°C ile 40°C (32°F ile 104°F) arasında olmalıdır. Ürünü sökmeyin. Servis veya onarım gerektiğinde, ürünü nitelikli bir servis personeline götürün. Yanlış montaj yangın veya yaralanma riski oluşturabilir.
5)Ürün uzun süre kullanılmadığında, her üç ayda bir şarj edip boşaltmalısınız.
6)Bir cihazı şarj ederken, ürün ısınabilir. Bu normal bir çalışma durumudur ve endişe nedeni olmamalıdır.
7)Normal koşullarda, pil performansı birkaç yıl içinde azalacaktır.
8)Ürünü ısıya veya ateşe atmayın.
9)Ürünü zararlı kimyasallar veya deterjanlarla temizlemeyin.
10Yanlış kullanım, düşürme veya aşırı kuvvet ürün hasarına neden olabilir.
11)İlkincil hücreleri veya pilleri atarken, farklı elektrokimyasal sistemlere sahip hücreleri veya pilleri birbirinden ayrı tutun.
12)Boşalmış bir pilin yangın veya duman çıkarabileceğini unutmayın. Terminalleri yalıtmak için bantlayın.

User Manual
All-in-one Power Stand

Overview



	Green LED : All of wireless output are ready, you can place the devices to get wireless charging.
	White LED : One or all off wireless output is working , please press the power button if you want to charge another device wirelessly.
	LED Off, Wireless Off

	1%-25%
	26%-50%
	51%-75%
	76%-100%

1.Wireless Charging Indicator
2. Battery Level Indicator
3. USB-C Port for Charging and Discharging.
4. Power Button
5. Foldable Stand
6.Wireless Charger for Phone
7.Wireless Charger for Watch
8.Wireless Charger for AirPods

Charge Your Devices Wirelessly.

NOTE: The Magnetic function only work with MagSafe charging phones (iPhone 12 / 13 / 14 series or later) or phones with a MagSafe case.
1.Press the power button to activate wireless charging.
2.Place the devices to designated area to get a charge.

Recharge the Power Bank

1. This power bank can be recharged the by a USB-C cable and Charger.
2. To have the best charging experience, a 20W or above charger is required

Charge Your Devices Via a Cable

The USB-C port is 20 Maximum output, you can use to charge other device by a cable.

Recharge the Power Bank and Your Device Together

The power bank support pass-through charging, you can charge the power bank and 3 devices at the same time.

1. Recharge the power bank by a cable and charger.
2. Place your wireless charging device on the wireless charging cion area.
3. Make sure your device is recharging.

Important Notes

This wireless charger is not compatible with non-MagSafe phone cases, such as Otterbox Defender cases.
1,Do not use an adapter with an output Less then 5V/2A (10W).
2.Wireless chargers make charging more convenient than wired chargers, but confined by current wireless technology, their charging speed is slower than that of wired chargers.
3.High temperatures will reduce charging speed and restrict power, which is something that happens to all wireless chargers. It is recommended that you charge your device inenvironments with temperatures below 25°C / 77°F.
4.Both the protective phone case and the position of your device on the wireless charger will affect the charging speed. The farther it is placed from the center of the wireless charger, the slower the charging speed will be.

Safety Instructions

When using this product, basic precautions should always be followed, including the following:
1.Store the product in a cool, dry place.
2.Do not store the product in a hot or humid environment.
3.Use of a power supply or charger not recommended or sold by the product manufacturer may result in a risk of fire or injury to persons.
4.Operating temperature should be between 0°C to 40°C / 32°F to 104°F.
5.Do not disassemble the product. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.
6.If the product is not used for long periods of time, you should charge and discharge it once every three months.
7.When charging a device, the product may feel warm. This is a normal operating condition and should not be a cause for concern.
8.In normal conditions, the battery performance will decline over several years.
9.Do not dispose of the product in heat or fire.
10.Do not clean the product with harmful chemicals or detergents.
11.Misuse, dropping, or excessive force may cause product damage.
12.When disposing of secondary cells or batteries, keep cells or batteries of different electrochemical systems separate from each other.
13.Be aware that a discharged battery may cause fire or smoke. Tape the terminals to insulate them.